

**MAGRAV POWER (MP) is not an electronic or electrical device that only works with electron as source of energy. It is a plasma device that uses the energy from the totality of the atom. Imagine having a tree planted in your backyard. You have a growing entity with this device. Always send your good intentions when you deploy your MAGRAV POWER to your electrical system. The MAGRAV POWER also functions as Power Factor Corrector Device for your electrical system. With plasma energy provided by the MAGRAV POWER, it nanocoats your electrical system in your homes and buildings making them your energy power source.**

**The “MP” will have plug-in systems to access Plasma Food, Health, Water and other Plasma systems.**



---

***WARNING***

---

***Always consult a  
Professional Electrician  
when connecting to the  
Power Grid***

---

## DO'S

1. Contact a Professional Electrician when connecting to the Main Breaker.
2. Mount MAGRAV POWER on Wall or Table Top
3. Connect Proper Polarity
4. Gradually Load the MAGRAV POWER
5. Allow 3-4 Weeks Use to obtain maximum potential
6. Keep the MAGRAV POWER in a place that is out of reach of children.
7. Send Good Intentions to it.

## DON'TS

1. DO NOT Wet the MAGRAV POWER
2. DO NOT Overload, Maximum 2KW
3. DO NOT invert Polarity
4. DO NOT send negative intentions to the MAGRAV POWER.




## HOW TO IDENTITY THE LIVE WIRE

Use a polarity tester device or a phase meter for LIVE wire identification. The LED lights up when it is a LIVE (+) wire.

If LED lights on both sockets, the one with the brightest light is the LIVE (+) wire.




## HOW TO CONNECT TO THE GRID AND LOAD



**Note: (1) It will take 3-4 weeks for the device to gradually optimize to its fullest; (2) Add Appliance load gradually in a period of one hour.**

# OPTION 1: HOW TO CONNECT TO A VEHICLE



## OPTION 2: HOW TO CONNECT TO A VEHICLE

